

Assembly Instruction

FABRIC

260g Backlit Fabric

SIZE

70.1"x39.8" (178x101cm)





1 Take out the counter from the carry bag and lay it on the floor



Pull it up by your hands lightly, and the frame will expand immediately with the special spring mechanism design



3 Cover the graphic on to the frame



4 Push the board to collapse the frame, and secure the graphic to the top and bottom boards of the counter using silicon strips sewn on the graphic edge



5 Pull the top board with your hands to expand the frame again



6 Unzip zipper on the side corner of the graphic, then connect the power supply to light the lamps.



7 The display counter is ready to use