

# Floor Grid Pop Up Display

## Assembly Instruction

### FABRIC

Flame-retardant 240g Elastic Polyester

### TYPE

1x3, 2x2, 2x3, 3x3, X, Double X,  
Triangular S,  
Triangular M,  
Triangular L



1 Lay the frame on the floor



2 Expand the frame with a slight pull by your hand



4 Each fabric panel is sewn with a grommet on each corner. Attach all the panels to the frame via the grommets



5 The setup is finished



**Outlet Tags Canopies**  
390 Progress Ave, Unit 16  
info@outlettags.com 416-298-0022