




CANOPY SET UP GUIDE

Step # 1

(a) Place the frame in a large open space. With two persons on opposite side, grab the two (V shape) center bars, and lift while walking backwards at the same time. Until extended at 50%



(b) Place the Canvas in the center, and even it out across the frame. Place the center piece (peak) directly on the center raising bar.

(c) Slide each Canvas corner down, using the Velcro strips to secure each other. Velcro attached to inside Canvas corner and Velcro attached to frame corner should be connected together.



Step # 2

Two persons take opposite side and raise the frame until fully extended. The Canvas will even out automatically while being raised. Lock each corner by raising the Canvas slightly. Place your finger on the push pin. If you find it stiff, **EXTEND THE FRAME MORE**. Be careful not to pinch your finger while locking the slider. Once locked, lower the raised Canvas over the slider. **YOUR TOP IS NOW FULLY SET UP ON THE FRAME**



Step # 3

With two or more people, Place your foot on the bottom peddle, and raise the frame at the SAME TIME using both hands. You will hear a locking click. Lock the slider at your desired height adjustment. The first locking is best for wind resistance. **AVOID** placing weight strain on a single side or leg. This can cause damage.



NEVER FORCE THE FRAME OPEN OR CLOSE. Use the Velcro or zipper walls to connect to the tent.

To close the Tent, reverse the steps. Visit OUTLETTAGS.COM for assistance or to inquire about accessories.

